


# Microphone & Accelerometer Frequency Response Enhancement




*by Tommy Schack & Ole Thorhauge*

# Response Equalisation Extreme – REq-X


## Agenda

- Introduction to Response Equalisation (*REq-X*)
- Transducers and their frequency responses
  - Microphones. Sound fields and their influence on measurement accuracy
  - Accelerometers. Resonancy frequency and effects of mounting principles
- How does *REq-X* work
  - Theory
  - Practical implementation
- Some illustrative examples
  - Microphones
  - Accelerometers
- Conclusion



# Introduction – Response Equalisation – eXtreme (*REq-X*)

## Transducer Response Equalisation in brief




### *REq-X*

- *expands* the use of existing transducers
- *improves* the accuracy of the measurement
- *extends* the frequency range of transducers


# Response Equalisation Extreme – REq-X

## Agenda


- Introduction to Response Equalisation (*REq-X*)
- Transducers and their frequency responses
  - Microphones. Sound fields and their influence on measurement accuracy
  - Accelerometers. Resonancy frequency and effects of mounting principles
- How does *REq-X* work
  - Theory
  - Practical implementation
- Some illustrative examples
  - Microphones
  - Accelerometer
- Conclusion





# Types of Microphones




Random incidence




# Free Field Correction



# Free Field Correction




# Use of Free Field Microphones







# Use of Random Incidence Microphones



# Use of Pressure Microphones



Small enclosures as couplers and artificial ears.




Surface pressure measurements

# Diffuse-field microphones - Interior noise

4942 frequency response


½" general purpose diffuse field microphone



# Free-field microphones - One noise source


4189 and 4190 frequency response

½" general purpose free field microphone




# Unknown sound field - Maximum error

Maximum possible error - any incidence




# Microphone frequency response

## Microphones are delivered with a Calibration Chart



## and a Microphone Data Disk




or



# Effect of microphone accessories!

## Example:


Effect of a  
microphone  
wind screen



# Response Equalisation Extreme – REq-X


## Agenda

- Introduction to Response Equalisation (*REq-X*)
- Transducers and their frequency responses
  - Microphones. Sound fields and their influence on measurement accuracy
  - Accelerometers. Resonancy frequency and effects of mounting principles
- How does *REq-X* work
  - Theory
  - Practical implementation
- Some illustrative examples
  - Microphones
  - Accelerometers
- Conclusion





# Accelerometers - Useful Frequency Range



# Calibration chart for an accelerometer

## Calibration Chart for Triaxial DeltaTron® Accelerometer Type 4524B



Brüel & Kjær

Serial No.: 300376

Reference Sensitivity<sup>1)</sup> at 159.2 Hz  
( $\omega = 1000 \text{ s}^{-1}$ ), 20 ms<sup>-2</sup> RMS,  
4 mA supply current and 23.8 °C:

| X- axis | Y- axis | Z- axis |
|---------|---------|---------|
| 9.979   | 10.03   | 10.11   |
| 97.86   | 98.31   | 99.11   |

Frequency Range Amplitude ( $\pm 10\%$ ): 0.2-5.5k 0.25-3.0k 0.25-3.0k Hz  
Phase ( $\pm 5^\circ$ ): 1.5-3.0k 1.5-3.0k 1.5-3.0k Hz

Mounted Resonance Frequency: 18 9 9 kHz

Transverse Sensitivity:  
Maximum (at 30 Hz, 100 ms<sup>-2</sup>) < 5 < 5 < 5 %

Transverse Resonance Frequency: 9 9 9 kHz

|   |       |       |       |       |
|---|-------|-------|-------|-------|
| Calculated values for TEDS <sup>2)</sup> : F <sub>res</sub> : | 18.6  | 8.64  | 9.89  | kHz   |
| Q:  | 15.2  | 185   | 162   |       |
| Amp. Corr.:   | -2.4  | -2.5  | -2.4  | %/dec |
| F <sub>0p</sub> :   | 0.010 | 0.010 | 0.010 | Hz    |
| F <sub>0p</sub> :   | 210   | 300   | 300   | kHz   |


Measuring Range:  $\pm 500 \text{ ms}^{-2}$  peak ( $\pm 50 \text{ g}$  peak)

Polarity of the electrical signals is positive for an acceleration in the direction of the arrows on the drawing.

<sup>1)</sup> This calibration is obtained on a modified Brüel & Kjær Calibration System Type 9610 System No.: 15025Z, and is traceable to the National Institute of Standards and Technology, USA and Physikalisch-Technische Bundesanstalt, Germany.  
The expanded uncertainty is 1.0% determined in accordance with EAL-2. A coverage factor  $k = 2$  is used. This corresponds to a coverage probability of 95% for a normal distribution.  
<sup>2)</sup> Transducer Electronic Data Sheet according to IEEE P 1451.4.

<sup>3)</sup> Deviation from Reference Sensitivity.  
Transducer principle patented US 5677487, US 8387851, US 5996412, JP 50952694, DK 169653.

For further information, please see <http://www.bksv.com> and Product Data Sheets.



### Electrical:

Bias Voltage: at full temperature and current range: +13 V  $\pm$  1 V

Power Supply Requirements: Constant Current: +2 mA to +10 mA  
Unloaded Supply Voltage: +24 V to +30 V

Note: All three axes must be powered!  
Single or dual axial supply is not possible.

Output Impedance: < 30  $\Omega$

Start-up Time (to 90% of bias): < 10 s

Inherent Noise, X-axis (RMS):  
Broadband (1 Hz to 6 kHz): < 40  $\mu\text{V}$

Spectral: corresponding to < 0.004 ms<sup>-2</sup> ( $\pm 400 \mu\text{g}$ )  
10 Hz:  $1.6 \times 10^{-4} \text{ ms}^{-2}/\sqrt{\text{Hz}}$  (16  $\mu\text{g}/\sqrt{\text{Hz}}$ )  
100 Hz:  $4 \times 10^{-5} \text{ ms}^{-2}/\sqrt{\text{Hz}}$  (4  $\mu\text{g}/\sqrt{\text{Hz}}$ )  
1000 Hz:  $2 \times 10^{-6} \text{ ms}^{-2}/\sqrt{\text{Hz}}$  (2  $\mu\text{g}/\sqrt{\text{Hz}}$ )

Inherent Noise, Y- and Z-axes (RMS):  
Broadband (1 Hz to 6 kHz): < 20  $\mu\text{V}$

Spectral: corresponding to < 0.002 ms<sup>-2</sup> ( $\pm 200 \mu\text{g}$ )  
10 Hz:  $0.8 \times 10^{-4} \text{ ms}^{-2}/\sqrt{\text{Hz}}$  (8  $\mu\text{g}/\sqrt{\text{Hz}}$ )  
100 Hz:  $2 \times 10^{-5} \text{ ms}^{-2}/\sqrt{\text{Hz}}$  (2  $\mu\text{g}/\sqrt{\text{Hz}}$ )  
1000 Hz:  $1 \times 10^{-6} \text{ ms}^{-2}/\sqrt{\text{Hz}}$  (1  $\mu\text{g}/\sqrt{\text{Hz}}$ )

Insulation Resistance (signal ground to case): > 1 G $\Omega$

Recommended Cables: AO 0526  
AO 0527  
AO 0528  
AO 0534

Built-in ID-information and TEDS<sup>3)</sup> according to IEEE P1451.4

### Mounting Technique:

The accelerometer can be fastened directly to the measuring object by glue, e.g., hot glue. However, if a reduced frequency range can be accepted, it is recommended to use one of the special mounting clips (see below) which is glued to the measuring object. In any case, the mounting surface must be clean and smooth.

Four types of mounting clips are available: UA 1407 (set of 100) is a low-profile clip recommended for mounting on plane surfaces. UA 1475 (set of 100) is a clip with a thick base which can be fitted to a curved mounting surface. UA 1564 (set of 5) is a high-temperature clip. UA 1478 (set of 100) is a swivel base clip for use where the accelerometer is to be aligned according to a given coordinate system.

Applying a little grease to the mounting surface of the accelerometer as well as the clip will improve the frequency response.  
See also ISO 5348.

### Environmental:

Temperature Range: -54 to +100°C (-65 to +212°F)

Temperature Coefficient of Sensitivity: +0.14%/°C

Temp. Transient Sensitivity (3 Hz Low Lim. Freq. (-3 dB, 6 dB/oct)): 0.002 ms<sup>-2</sup>/°C

Magnetic Sensitivity (50 Hz, 0.038 T): 20 ms<sup>-2</sup>

Base Strain Sensitivity (at 250  $\mu\text{m}$  in base plane):  
Mounted in Mounting Clip or on adhesive tape 0.09 mm thick: 0.0005 ms<sup>-2</sup>/ $\mu\text{m}$

Max. Non-destructive Shock: 50 kms<sup>-2</sup> peak (5000 g peak)

Humidity: Hermeti

### Mechanical:

Case Material: Titanium ASTM Grade


Sensing Element: Piezoelectric, Type PZ 2

Construction: OrthoShear

Sealing: Hermeti


Weight: 4.4 gram (0.15 oz)

Electrical Connector: 4 pin, 1/4" - 28 UNI  
(Microtech compatible)  
All pins insulated from cas



Mounting Surface Flatness:

< 3  $\mu\text{m}$




Date 06 sep 2006, 09:51 Operator LN

Specifications obtained in accordance with ANSI S2.11-1969 and ISO 5347.

Except for the frequency range all values are typical at 25°C (77°F) unless measurement uncertainty is specified.

BC 0367-12


# Accelerometer Mounting



# Response Equalisation Extreme – REq-X

## Agenda


- Introduction to Response Equalisation (*REq-X*)
- Transducers and their frequency responses
  - Microphones. Sound fields and their influence on measurement accuracy
  - Accelerometers. Resonancy frequency and effects of mounting principles
- How does *REq-X* work
  - Theory
  - Practical implementation
- Some illustrative examples
  - Microphones
  - Accelerometers
- Conclusion



# Response Equalisation theory


## Frequency Domain Response Equalisation

Equalisation is done by multiplying the Input Frequency Responses and the Equalisation Frequency Response.




## Time Domain Response Equalisation

Equalisation is done by Filtering the Input with the Equalisation Filter.  
Done by convolution of the Input and the Equalisation Impulse Response.



# Calculation of FIR filter



$$N = \frac{f_s}{\Delta f}$$

$$\Delta t = \frac{1}{f_s}$$

$$T = N \times \Delta t$$

Example:


$$\left. \begin{aligned} f_{\text{span}} &= 25.6 \text{ kHz} \\ f_s &= 2.56 \times f_{\text{span}} \\ &= 65536 \text{ Hz} \\ \Delta f &= 128 \text{ Hz} \end{aligned} \right\} \Rightarrow \left\{ \begin{aligned} N &= \frac{f_s}{\Delta f} = \frac{65536 \text{ Hz}}{128 \text{ Hz}} = 512 \\ \Delta t &= \frac{1}{f_s} = \frac{1}{65536} \text{ s} \\ T &= N \times \Delta t = \frac{512}{65536} \text{ s} = \frac{1}{128} \text{ s} \end{aligned} \right.$$

$f_{\text{span}}$  = Maximum frequency span     $T$  = Length of impulse response

# Response Equalisation Extreme – REq-X

## Agenda

- Introduction to Response Equalisation (*REq-X*)
- Transducers and their frequency responses
  - Microphones. Sound fields and their influence on measurement accuracy
  - Accelerometers. Resonancy frequency and effects of mounting principles
- How does *REq-X* work
  - Theory
  - Practical implementation
- Some illustrative examples
  - Microphones
  - Accelerometers
- Conclusion



# Adding frequency response to data base

**Database Administrator**

Transducer

Serial No: 2455242 Family: Microphone

Nom.Sensitivity: 50 mV/Pa Type: 4190

CCLD: ☐ Name: 4190

Pol. Voltage: ☒

Max. Output Level:

Description: "Low-noise Free-field 1/2" Microphone"

Frequency: 251.2 Hz  
Lower Frequency(-3dB): 1.4 Hz  
Polarization Voltage: 200 V

Accredited Calibration

Sensitivity: 50.5 mV/Pa

Capacitance: 16.6 pF Time: 8/24/2004 12:00:00 PM

Operator: AAJ  
Reference Temperature: 23 Celsius  
Reference Static Pressure: 101.3 kPa  
Reference Relative Humidity: 50 %

Local Calibration

Sensitivity: <number> mV/Pa

Capacitance: <number> pF Time: 9/9/2006 6:22:23 PM

This is a comment field

Store Clear Close

Transducer Type

Edit / Add Read

Transducer

Find **Read** History

Correction Curve

Curve: Actuator Response

[dB/1.00 V/Pa]

0  
-5  
-10  
-15

1k 10k [Hz]

Date: 24. Aug 2004  
Operator: AAJ  
Temperature: 23 Celsius  
Static Pressure: 100.9 kPa



# Adding frequency response to data base

## Calibration Chart for Triaxial DeltaTron® Accelerometer Type 4524B

Serial No.: 300376



|   | X-       | Y-        | Z-        | axis                |
|---|----------|-----------|-----------|---------------------|
| <b>Reference Sensitivity<sup>1)</sup></b> at 159.2 Hz<br>( $\omega = 1000 \text{ s}^{-1}$ ), 20 ms <sup>-2</sup> RMS,<br>4 mA supply current and 23.8 °C: | 9.979    | 10.03     | 10.11     | mV/ms <sup>-2</sup> |
|   | 97.86    | 98.31     | 99.11     | mV/g                |
| <b>Frequency Range</b>  | 0.2-5.5k | 0.25-3.0k | 0.25-3.0k | Hz                  |
| Amplitude ( $\pm 10\%$ ):   | 1.5-3.0k | 1.5-3.0k  | 1.5-3.0k  | Hz                  |
| Phase ( $\pm 5^\circ$ ):  |          |           |           |                     |
| <b>Mounted Resonance Frequency:</b>   | 18       | 9         | 9         | kHz                 |
| <b>Transverse Sensitivity:</b>  |          |           |           |                     |
| Maximum (at 30 Hz, 100 ms <sup>-2</sup> )   | < 5      | < 5       | < 5       | %                   |
| <b>Transverse Resonance Frequency:</b>  | 9        | 9         | 9         | kHz                 |
| <b>Calculated values for TEDS<sup>2)</sup>:</b>   |          |           |           |                     |
| F <sub>res</sub> :  | 18.6     | 8.64      | 9.89      | kHz                 |
| Q:  | 15.2     | 185       | 162       |                     |
| Amp. Corr.:   | -2.4     | -2.5      | -2.4      | %/dec               |
| F <sub>hp</sub> :   | 0.010    | 0.010     | 0.010     | Hz                  |
| F <sub>lp</sub> :   | 210      | 300       | 300       | kHz                 |

**Measuring Range:**  $\pm 500 \text{ ms}^{-2}$  peak ( $\pm 50 \text{ g}$  peak)

**Polarity** of the electrical signals is positive for an acceleration in the direction of the arrows on the drawing.

<sup>1)</sup> This calibration is obtained on a modified Brüel & Kjær Calibration System Type 9610 System No.:  
National Institute

Elec

Bias \

Power

Noti  
Sing

Out

Start

Inher  
Broar

Spec

Inht  
Bro

Spe

Ins.

Rec

**Database Administrator**

Transducer:  Family: Accelerometer  
 Nom.Sensitivity: 10 mV/ms<sup>-2</sup> Type: 4524 x  
 CCLD: ☒ Name: 4524 x  
 Weight: 4.4 g  
 Max. Output Level: 5.0 V  
 Description: DeltaTron Acc

**TEDS values**

Resonance Frequency: 18.6 kHz  
 Quality Factor: 15.2  
 Amplitude Slope: -2.4 %/decade  
 High Pass Cut-off Frequency: 0.01 Hz  
 Low Pass Cut-off Frequency: 210 kHz

OK Cancel

Time: 9/7/2006 2:00:41 PM

This is a comment field

Store Clear Close


Transducer Type  
 Edit / Add Read

Transducer  
 Find Read History


Correction Curve  
 Curve: Frequency Response  
 TEDS values  
 [dB/1.00]

20  
10  
1 1k [Hz]



# Step by step – how to use REq-X




# Step by step – how to use REq-X




All possible equalisation curves available for 4190



# Step by step – how to use REq-X




- Transducer Frequency Response
- Correction Filter Response
- Equalised (true) Frequency Response



# Response Equalisation Extreme – REq-X



## Agenda

- Introduction to Response Equalisation (*REq-X*)
- Transducers and their frequency responses
  - Microphones. Sound fields and their influence on measurement accuracy
  - Accelerometers. Resonancy frequency and effects of mounting principles
- How does *REq-X* work
  - Theory
  - Practical implementation
- Some illustrative examples
  - Microphones
  - Accelerometer
- Conclusion



# REq-X with microphones – example


**Measurement example:  
4190 used with wind screen  
in free field**



# REq-X with microphones – example



Measurement example:

4190 used with wind screen in free field



# REq-X with microphones – example


## Measurement example 4190 used in diffuse field





# REq-X with microphones – example

## Measurement example – 4190 used in diffuse field




# REq-X with Microphones

- REq-X improves measurement accuracy by up to 1.5dB over the frequency range
- REq-X corrects for angle of sound-field incidence and microphone accessories thus **improving accuracy** by a further 5-10 dB

## *Expand the use of your existing Microphones*

- Basically any microphones can now be used for pressure, diffuse and free-field measurements




*Frequency response of a free field microphone used as a diffuse field microphone and its equalised frequency response*

- The correction is specific to a given microphone, relying on its calibration data supplied with the microphone CD from the factory. This CD can be read directly into the PULSE Transducer Database.

# Response Equalisation Extreme – REq-X

## Agenda

- Introduction to Response Equalisation (*REq-X*)
- Transducers and their frequency responses
  - Microphones. Sound fields and their influence on measurement accuracy
  - Accelerometers. Resonancy frequency and effects of mounting principles
- How does *REq-X* work
  - Theory
  - Practical implementation
- Some illustrative examples
  - Microphones
  - Accelerometers
- Conclusion




# REq-X with Accelerometers – example

## Measurement example – 4507 mounted with metal clip

Resonance frequency = 19 kHz

+10% at 7.0 kHz without REq-X

+10% at 12.0 kHz with REq-X




# REq-X with Accelerometers – example

## Measurement example – 4507 mounted with grease

Resonance frequency = 19 kHz



+10% at 6.1 kHz without REq-X

+10% at 9.2 kHz with REq-X



# REq-X with Accelerometers

- REq-X halves measurement inaccuracy
- REq-X extends accelerometer frequency ranges
  - Uni-axial up to **100%**, other typical up to **50%**.
  - In practise it often makes sense to correct higher in frequency




- The correction for accelerometers is automatically calculated from TEDS

# Response Equalisation Extreme – REq-X

## Agenda

- Introduction to Response Equalisation (*REq-X*)
- Transducers and their frequency responses
  - Microphones. Sound fields and their influence on measurement accuracy
  - Accelerometers. Resonancy frequency and effects of mounting principles
- How does *REq-X* work
  - Theory
  - Practical implementation
- Some illustrative examples
  - Microphones
  - Accelerometer
- Conclusion



# Conclusion!

## User benefits:

### ***REq-X “Response Equalisation – eXtreme”***

- **expands** the use of new and existing transducers.
- **improves** the accuracy of the measurement
- **extends** the frequency range of transducers
- work in **real-time** –any PULSE measurement and analysis will benefit from this

*The bottom line is that if you want the highest possible measurement accuracy result – then you need REq-X*

