

Modal Shakers and Accessories

that makes Modal Testing more accurate and
easier to setup

Host : Robert Trépanier, eng.

Filename, 1

Brüel & Kjær 

**Please mute your telephone microphone
during the presentation if you do not have
to ask questions. This will keep the
background noise down and help a lot
during the presentation.**

Filename, 2

Brüel & Kjær 

The attached modal excitation solution



Complete Program!

- Competitively priced
- Full range (5) of dedicated modal excitors
- Full program of stingers
- Two robust exciter stands
- Complete range of modal impact hammers

Superior Performance!

- Proven, **durable** design
- Proven **highest force-to-weight** ratio
- Faster and more **productive** test
- Improve **reliability** and **consistency** of mobility measurements
- **Safe** and **easy** operation with maximum **protection** of equipment, test structure and test engineers


One-Stop-Shop

Aiming to provide our customers with the industry's best and most complete tools for modal testing

Filename, 3

Brüel & Kjær

Role of the transducer in the measurement chain



No chain is stronger than its weakest link!

010017


Filename, 4

Brüel & Kjær

In theory modal testing is straight forward

Shaker method:

- *Excitation* of the structure at *one point* by shaker with force transducer
- *Response* measured at *a number of points*
- FRF's between excitation point and measurement points calculated
- Modes of structure identified




Filename, 5

Press anywhere
to advance animation

Brüel & Kjær

...but in practice, accuracy is difficult to achieve

A state-of-the Art Assessment of Mobility Measurement Techniques
Repeatability results for a Round Robin Test (30 - 3000 Hz) 1981




Filename, 6

Brüel & Kjær

GARTEUR “Round Robin” Test: Level 4 DTA

- Under the auspices of Group for Aeronautical Research and Technology in Europe (GARTEUR): Twelve experienced GVT units from all of Europe performed modal test of the same test specimen (ref. NLR TP 97086U, 1996)
- Results in terms of **repeatability**
 - Damping ratio: ~ 30%
 - Modal frequencies: ~ 4%
- Results in terms of generalized mass **repeatability**:
 - Flutter prediction accuracy: ~ 13%



Filename, 7

Brüel & Kjær

Purpose of the new modal excitors

- Higher force measurement, **accuracy** and **precision**
- Faster and more **productive** test
- Improve **reliability** and **consistency** of mobility measurements
- **Safe** and **easy** operation with maximum **protection** of equipment, test structure and test engineers

and.....

*maintain or improve legendary quality and longevity of
Brüel & Kjær excitors and power amplifiers*



- One stop shopping -

**Aiming to provide our customers with
the industry's best and most complete
tools for modal testing**

Filename, 8


Brüel & Kjær

Achieving high quality FRFs: input aspects



- Minimizing Exciter/Test Structure Interaction
 - *Solution: Low weight magnesium armature!*
- Obtaining Valid Force Measurements
 - *Solution: Stinger with lowest possible bending stiffness!*
- Distributing and Minimizing Dynamic Force Levels
 - *Solution: Flexible and versatile set-up!*
- Exciter ability to “survive” large side loads
 - *Solution: Rugged construction with 2 x 4 springs!*

- Choosing Best Exciter Location
 - *Solution: Low total weight of exciter and trunnion!*
- Low Frequency Modal Test Performance
 - *Solution: Highest possible peak-to-peak displacement!*



Filename, 9

Brüel & Kjær

Means of implementing excitation

- Standard Methods
 - Attached: Electromagnetic exciter
 - Non-attached: Instrumented impact hammer



- Non-standard Methods
 - Electrohydraulic exciters
 - Eccentric rotating masses
 - Drop hammers
 - Pendulum impactors
 - Suspended cables
 - Rockets
 - Jet engines
 - Acoustic excitation (unscaled mode shapes)



Filename, 10

Brüel & Kjær

Impact Hammer Excitation



Conclusion

- Use for poor man's modal
- Best suited for field work
- Useful for determining shaker and support locations

Advantages:

- Speed
- No fixturing
- No variable mass loading
- Portable and highly suitable for field work
- relatively inexpensive

Disadvantages

- High crest factor means possibility of driving structure into non-linear behavior
- Tip Performance is often overlooked
- Not good for very large structures
- Repeatable hammer strikes require 'calibrated elbow'

Filename, 11

Brüel & Kjær

Shaker Excitation



Conclusion

- Best suited for lab work
- Good on very light, very large, and difficult objects
- Tests requiring high degree of repeatability

Advantages:

- Repeatable due to electronic control
- Wide range of excitations
- Can excite very small thru very large structures
- More automated test

Disadvantages

- More equipment required than hammer
- Skilled operators necessary to supervise test
- A lot of setup time required
- Shaker issues such as: stingers, mounting of shaker, proper shaker selection

Filename, 12

Brüel & Kjær

Permanent magnet modal excitors

- Type 4824/3624

- Force rating: **100N** (sine)
- Frequency range: DC - 5000 Hz
- Max. rated travel: **25.4 mm (1")**
- Armature effective mass: **0.23kg**
- Weight with trunnion: **21 kg**
- Power Amplifier Type 2732
- DC Static Centering Unit optional



4824.pdf

- Type 4825/3625

- Force rating: **200N** (sine)
- Frequency range: DC - 5000 Hz
- Max. rated travel: **25.4 mm (1")**
- Armature effective mass: **0.23 kg**
- Weight with trunnion: **21 kg**
- Power Amplifier Type 2720
- DC Static Centering Unit optional



4825_4826.pdf

- Type 4826/3626

- Force rating: **400N** (sine)
- Frequency range: DC - 5000 Hz
- Max. rated travel: **25.4 mm (1")**
- Armature effective mass: **0.40 kg**
- Weight with trunnion: **21 kg**
- Power Amplifier Type 2721
- DC Static Centering Unit optional



4825_4826.pdf



Filename, 13

Brüel & Kjær

Electromagnet modal excitors

- Type 4827/3627

- Force rating: **650N** (sine)
- Frequency range: DC - 5000 Hz
- Max. rated travel: **50.8 mm (2")**
- Weight with trunnion: 80 kg
- Power Amplifier Type 2721
- DC Static Centering Unit needed
- Field Power Supply needed



4827_4828.pdf

- Type 4828/3628

- Force rating: **1000N** (sine)
- Frequency range: DC - 5000 Hz
- Max. rated travel: **50.8 mm (2")**
- Weight with trunnion: 80 kg
- Power Amplifier Type 2721
- DC Static Centering Unit needed
- Field Power Supply needed

Filename, 14

Brüel & Kjær

Power amplifiers

- **Type 2732** →

- Drives Type 4824 to full 100N force rating
- 120 VA output capacity
- Extensive protective features
- Voltage and current mode



2732.pdf

- **Type 2720** →


- Drives Type 4825 to full 200N force rating
- 500 VA output capacity
- Extensive protective features
- Voltage and current mode



2720.pdf

- **Type 2721** →

- Drives Type 4826, 4827 and 4828 to full force ratings
- 1250 VA output capacity
- Extensive protective features
- Voltage and current mode




2721.pdf

Filename, 15

Brüel & Kjær

Lateral modal exciter stands

- Two rugged stands for easy lateral exciter suspension: height **1.4 meters** and **2.0 meters**
- Exciter with trunnion is suspended from arm using four turnbuckles
- Inertia masses may be added to trunnion to increase reaction force
- Tension wire or push/pull stinger
 - Spring for mechanical pre-tensioning and turnbuckle for adjustment comes as standard accessory (used only with tension wire stinger)
- Heavy-duty wheels for maximum mobility and ease of set-up
 - Wheels can be locked during excitation
 - Base with through holes for ease of permanent installation
- Exciter is positioned by means of spindle (vertically) and displaced back and forth on arm (horizontally)



Bp1973.pdf

Filename, 16

Brüel & Kjær

Stingers and adaptors: Push/pull



- Flexible length (500 mm max)
- Large diameter (**UA 1599**), ideal for Types 4827 and 4828
- Medium diameter (**UA 1598**), ideal for Types 4824, 4825 and 4826




- Fixed length (120 mm)
- Set of 20 nylon stingers (**WZ 0066**), works with Types 4824, 4825, 4826, 4827 and 4828
- Compromise between max. transferable force, weight and bending stiffness. Low weight and good mechanical fuse but low forces can be transferred

- 
- Fixed length (200 mm)
 - Large diameter (**UA 1597**), ideal for Types 4827 and 4828
 - Medium diameter (**UA 1596**), ideal for Types 4824, 4825 and 4826

Filename, 17

Brüel & Kjær 

Stingers and adaptors: tension (piano) wire




- Type number **UA 1600**. Spool Length 5000 mm
- Best accuracy and precision: Low weight, almost zero bending stiffness!
- Any length possible during test, but the shorter the length, the higher excitation frequency is possible
- Easy alignment during set-up
- Needs pre-tensioning
- Can not transfer as high force as push/pull stingers
- Frequency range 0 Hz to approximately 400 Hz

Filename, 18

Brüel & Kjær 

Stingers and adaptors: thread adaptors



- Four sets of collet chucks and adaptors for four different stinger diameters.
- Each set contains three collet chucks and three adaptors.
- Type numbers: UA1602, UA1603, UA1604, UA1605
- Use as spare parts or for attachment of custom made stingers

Types UA1612 and UA1614:
Three thread adaptors

Filename, 19

Brüel & Kjær

Features, advantages and benefits

Attached energy source features required
for a successful modal test

- High **force-to-weight** ratio **unique point!**
- High **force-to-price** ratio
- Wide **frequency** ranges
- Smaller types (armature suspended in springs) with full **1" peak-to-peak displacement** for best low frequency performance
- Larger types (armature guided in rolls and suspended with a static DC current from DC Static Centering Unit) with **2" peak-to-peak displacement** for best low frequency performance



Filename, 20

Brüel & Kjær

Features, advantages and benefits



Attached energy source features required for a successful modal test

- Armature with **high rigidity** and **low mass**
- **Low total weight** of exciter allowing for easy positioning and orientation relative to test object
- Dedicated robust **lateral exciter stands** for easy positioning and orientation.
- All types prepared for attachment and pre-tensioning of **piano wire stinger** technology
- **Hole-through** design on Types 4824, 4825 and 4826 for mechanical pre-tensioning of piano wire stingers
- Complete line of **accessories**, incl. various stingers (push/pull and tension)



Filename: 21

Brüel & Kjær

Customers, applications and key issues



Less experienced modal people who wish to upgrade their existing test systems (non-dedicated modal laboratories)

Very little modal experience.
broad range of industries

Experienced modal people within the aerospace & automotive industry (dedicated modal laboratories)

Applications:

- High accuracy and high precision modal test
- Static mass: Structures from 50 kg to 2000 kg (coarse estimate!)
- Dynamic mass: Structures from 0 kg to 200,000 kg (coarse estimate!)

Key issues:

- High force-to-weight ratio
- High force-to-price ratio
- Peak-to-peak displacement
- Long lived operation
- True one stop shopping with all accessories
- Dedicated and purposeful design

Filename: 22

Brüel & Kjær

Applications: automotive



RDT&E

- Modal testing
- Components design
- Engine/exhaust testing
- NVH analysis

Filename, 26

Brüel & Kjær 

Applications: space and flight testing

Spacecraft development

- Structural testing
- Thermal cycling
- Components testing

Design & verification tests on launch vehicles/rockets

- Structural testing
- Shock testing
- Vibro-acoustic testing

Rocket engines test & development

- Structural testing
- Failure analysis
- Vibration Testing at extreme temperature



Filename, 27

Brüel & Kjær 

Applications: space and flight testing



Aircraft Design & Manufacturing

- Structural analysis
- Landing gear testing
- Vibro-acoustic testing




Helicopter Design & Maintenance

- Structural analysis
- Engine/transmission testing
- NVH testing

Gas Turbine Design & Testing

- Structural analysis
- Failure analysis
- Engine tuning
- Test cell maintenance
- Repair/Overhaul




Filename, 28

Brüel & Kjær

Modal test set-up challenges

Accelerometer mounting:

- Stud
- Glue
- Wax
- (Magnet)



Force Transducer and Shaker:


- Stud
- Stinger (Connection Rod)

- Advantages of Stinger:
- No Moment Excitation
 - No Rotational Inertia Loading
 - Protection of Shaker
 - Protection of Transducer
 - Helps positioning of Shaker

Filename, 29

Brüel & Kjær


Modal test se-up challenges



Filename, 30

Brüel & Kjær

Modal test set-up challenges



Filename, 31

Brüel & Kjær

Remedy: tests for validity of data

Coherence

$$\gamma^2(f) = \frac{|G_{FX}(f)|^2}{G_{FF}(f) G_{XX}(f)}$$

Linearity

$$\left. \begin{array}{l} X_1 = H \cdot F_1 \\ X_2 = H \cdot F_2 \end{array} \right\} \Rightarrow \left\{ \begin{array}{l} X_1 + X_2 = H \cdot (F_1 + F_2) \\ a \cdot X_1 = H \cdot (a \cdot F_1) \end{array} \right.$$

Reciprocity

$$H_{ij}(f) = H_{ji}(f)$$


Filename, 32

Brüel & Kjær 


Remedy: check of driving point measurement

- All peaks in


$$\text{Im}\left[\frac{X(f)}{F(f)}\right], \text{Re}\left[\frac{X(f)}{F(f)}\right] \text{ and } \text{Im}\left[\frac{X(f)}{F(f)}\right]$$



- An anti-resonance in Mag $[H_{ij}]$ must be found between every pair of resonances



- Phase fluctuations must be within 180°




Filename, 33

Brüel & Kjær 


Remedy: Free Mass Calibration




$$A(f) = \frac{a(f)}{F(f)} = \frac{a(f)}{m a(f)} = \frac{1}{m}$$



$$\text{Mag} \left| \frac{a(f)}{F(f)} \right|$$



$$\angle \frac{a(f)}{F(f)}$$




Filename, 34

Brüel & Kjær

Basic measurement configuration

Mechanical System




Multi-analyzer

Filename, 35 930624

Brüel & Kjær

Types of excitation signals




Filename, 36


Brüel & Kjær

Broadband signals

Implementation



Waveform



Spectrum

Filename, 37

Brüel & Kjær

Excitation technique: Important Considerations


Consideration of:

- Application
- Non-linearities
- Speed of test
- Leakage (analysis)
- Dynamic range
- Crest factor
- Noise at input and/or output
- Equipment available

Filename, 38

Brüel & Kjær 


Swept sine technique



Filename, 39


Brüel & Kjær 

Sine excitation



$$\text{Crest factor} = \frac{A}{\text{RMS}} = \sqrt{2}$$

- For study of non-linearities,
e.g. harmonic distortion
- For broadband excitation:
 - Sine wave swept slowly through
the frequency range of interest
 - Quasi-stationary condition



Filename, 40

Brüel & Kjær

Swept sine excitation

Advantages

- Low Crest Factor
- High Signal/Noise ratio
- Input force well controlled
- Study of non-linearities
possible

Disadvantages


- Very slow
- No linear approximation of
non-linear system



Filename, 41

Brüel & Kjær

FFT technique



Filename, 42


Brüel & Kjær

Random excitation




Random variation of amplitude and phase
⇒ Averaging will give optimum linear
estimate in case of non-linearities


$G_{AA}(f), N = 1$



$G_{AA}(f), N = 10$



System Output
 $B(f_1)$



Filename, 43



Brüel & Kjær

Random excitation

- Random signal:
 - Characterized by power spectral density (G_{AA}) and amplitude probability density ($p(a)$)



- Can be band limited according to frequency range of interest



- Signal not periodic in analysis time \Rightarrow Leakage in spectral estimates

Filename, 44

Brüel & Kjær

Random excitation

Advantages

- Best linear approximation of system
- Zoom
- Fair Crest Factor
- Fair Signal/Noise ratio

Disadvantages

- Leakage
- Averaging needed (slower)

Filename, 45

Brüel & Kjær

Burst random

- Characteristics of Burst Random signal :
 - Gives best linear approximation of nonlinear system
 - Works with zoom



Advantages

- Best linear approximation of system
- No leakage (if rectangular time weighting can be used)
- Relatively fast

Disadvantages


- Signal/noise and crest factor not optimum
- Special time weighting might be required

Filename, 46


Brüel & Kjær

Pseudo random excitation

- Pseudo random signal:
 - Block of a random signal repeated every T



- Time period equal to record length T
 - Line spectrum coinciding with analyzer lines
 - No averaging of non-linearities





Filename, 47

Brüel & Kjær

Pseudo random excitation

- Pseudo random signal:
 - Characterized by power/RMS (G_{AA}) and amplitude probability density ($p(a)$)
- Can be band limited according to frequency range of interest



Time period equal to T
⇒ No leakage if Rectangular weighting is used

Filename, 48

Brüel & Kjær

Pseudo random excitation

Advantages

- No leakage
- Fast
- Zoom
- Fair crest factor
- Fair Signal/Noise ratio

Disadvantages



- No linear approximation of non-linear system





Filename, 49

Brüel & Kjær

Impact excitation



- Magnitude and pulse duration depends on:
 - Weight of hammer
 - Hammer tip (steel, plastic or rubber)
 - Dynamic characteristics of surface
 - Velocity at impact
- Frequency bandwidth inversely proportional to the pulse duration






Filename, 50

Brüel & Kjær

Weighting functions for impact excitation

- How to select shift and length for transient and exponential windows:



- Leakage due to exponential time weighting on response signal is well defined and therefore correction of the measured damping value is often possible

Filename, 51

Brüel & Kjær

Impact excitation

Advantages

- Easy to use in the field
- No elaborate fixturing
- Fast

Disadvantages

- No linear approximation of non-linear system
- Limited control of excitation bandwidth
- Special weighting functions in order to increase Signal/Noise ratio and/or avoid truncation errors




Filename, 52

Brüel & Kjær


Random impact excitation

As recorded



- More energy per time record than single impact
- Lower crest factor than single impact
- Useful for long record time i.e.:
 - low frequencies
 - zoom measurements

As analysed



Filename, 53

Brüel & Kjær

Random impact excitation



Advantages

- Easy to use in the field
- No elaborate fixturing
- Fast
- Lower crest factor than single impact

Disadvantages

- High crest factor
- Only useful at low frequencies or zoom
- No linear approximation of non-linear system
- Limited control of excitation bandwidth
- Leakage



Filename, 54

Brüel & Kjær

Guidelines for choice of excitation technique

- For study of non-linearities: → Swept sine excitation
- For slightly non-linear system: → Random excitation
- For perfectly linear system: → Pseudo random excitation
- For fields measurements: → Impact excitation
- For high resolution field measurements: → Random impact excitation

Filename, 55

Brüel & Kjær

Tips and tricks for best results

- **Verify measurement chain integrity prior to test:**
 - transducer calibration
 - Mass Ratio calibration
- **Verify suitability of input and output transducers:**
 - operating ranges (frequency, dynamic range, *phase* response)
 - mass loading
 - mounting
 - sensitivity to environmental effects
 - stability
- **Verify suitability of test set-up:**
 - transducer positioning and *alignment*
 - pre-test: rattling, boundary conditions, rigid body modes, signal-to-noise ratio, linear approximation, excitation signal, repeated roots, maxwell reciprocity, force measurement, exciter-input transducer-stinger-structure connection

- **Remember:**

- quality FRF measurements are the foundation of experimental modal analysis!

Filename, 56

Brüel & Kjær 

Stingers: key link for accuracy



- Purpose:
 - To **only transmit force in the sensitive direction** of the force transducer/impedance head
 - **Mechanical fuse** - protection of structure and exciter
 - Make structure/exciter alignment easier
- Ideal stinger: **zero bending stiffness** and indefinite axial stiffness and no mass
- Practical designs:
 - Tension wire (characteristics: zero bending stiffness, low mass)
 - Push/pull (characteristics: some bending stiffness, more mass)
- Conclusion: **use tension wire** whenever possible
- Limitation of tension wire:
 - Structure must not move when preloaded!
 - Set-up is more time consuming
 - Pre-load must be applied and verified
 - Limited force (< 200 N sine peak) and frequency (< 400 Hz)

Filename, 57

Brüel & Kjær 

The End!
Any Questions?

robert.trepanier@bksv.com

Filename, 58

Brüel & Kjær 